

## PROGRAMMING THE TIMER


### A. 7 Day Time Clock button descriptions

1. **(P)** : Programs review & setting programs
  2. **MANUAL**: To select “**ON,AUTO** or **OFF**”
  3. **(L)** : To adjust current **DAY** and **TIME**.
  4. **D+** : To adjust Day of week
  5. **H+** : To adjust Hour
  6. **M+** : To adjust Minute
  7. **RESET** : Reset Timer’s setting
  8. **LED** : To indicate ON/OFF status
- Press **RESET** button to reset Timer before programming

### B. Adjusting the CLOCK

Press and hold **(L)** and then press **D+**key, **H+**key, **M+**key respectively to adjust clock of Timer to current **DATE, HOUR, MINUTE**. **LCD** screen shall display 0:00~23:59

### C. Programming the TIMER

1. Press **(P)** key. **LCD** screen will show 
2. Press **D+** key to select any of 15 preset programs
3. Press **H+**, **M+** respectively to set desired Hour and Minute you want the timer to close contact.
4. After finished setting of **1** Press **(P)** key again,  will display on the **LCD** screen.
5. Press **D+** key to select any of the 15 preset programs.
6. Press **H+**, **M+** respectively to set desired Hour and Minute you want the timer to open contact.
7. Repeat Programming procedure “**3**” to set desired Hour & Minute for **1**
8. When finished setting **1 & 1**, Press **(P)**  will appear on LCD screen.
9. Repeat programming procedure above to complete up to 17 ON/OFF events
10. When you are finished setting times, press **(L)** to execute the programmed functions.

## CAUTION

1. For voltage and electrical RATING information, please refer to the markings on the back of timer.
2. Timer may need to be connected to power source in order to set the program.
3. Press RESET key before first use to clear memory.
4. Do not immerse timer in the water or any other liquid.